

















Romnes Nok system

Etiketter til bremsrør nipler (Quick 0001)

		www.uparts.no				www.uparts.no	
1	 <p>M10x1 L=16,7</p> <p>QUI A</p>	 <p>M10x1,25³ L=14,2</p> <p>QUI M</p>	3	1	 <p>M10x1 L=14</p> <p>QUI E</p>	 <p>M12x1³ L=20</p> <p>QUI B5,0</p>	3
2	 <p>M10x1 L=18</p> <p>QUI TX</p>	 <p>M10x1,25 L=19,5</p> <p>QUI L</p>	4	2	 <p>M12x1 L=18</p> <p>QUI B</p>	 <p>3/8x24 L=14,4</p> <p>QUI J</p>	4
		www.uparts.no				www.uparts.no	
1	 <p>3/8x24 L=18</p> <p>QUI S</p>	 <p>3/8x24³ L=16</p> <p>QUI KX</p>	3	1			3
2	 <p>3/8x24 L=21</p> <p>QUI F</p>	 <p>3/8x24 L=17,5</p> <p>QUI H</p>	4	2			4